


BLYSS USER MANUAL



This beautiful egg is unique. Made of super soft silicone, it'll give you an experience that's exquisite. Use alone or with a partner, insert the egg into the vagina and press the remote control to feel the gentle thrusting get to work on your g-spot. Hand over the controls to a partner for couples play.

SPECIFICATIONS

Size: 33mm x 85mm
Weight: Egg:46g Remote Controller:13g
Vibration Frequency: 7
Material: ABS + Silicone
Charging Time : 120 min
User time: 90min
Waterproof: 100% waterproof

FEATURES

1. Material: Ultra-premium silicone. 100% safe, phthalate-free and latex-free
2. Waterproof
3. Rechargeable
4. 10 suction patterns
5. 20 vibration patterns

SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Charge the toy. The light will blink on and off during charging and will light up continuously when unit is fully charged.
3. Wash with Share Satisfaction toy wash.
4. Apply Share Satisfaction water-based lubricant.
5. Turn on your 'BLYSS' sex toy by pressing the button on the toy or the remote control. Short presses to cycle through the 7 different modes.
6. Gently insert the eggs into the vagina.
7. To change the mode of vibration, simply press the mode, M button on the remote control.
8. This product has a 12 month warranty, which covers product replacement for manufacturing defects only.
9. Warning - this product is for adults only. Do not use on swollen, inflamed or broken skin. No medical claims are warranted or implied by the use of this product.
10. Do not charge near water.



SHARESATISFACTION.COM