







SHARE SATISFACTION CHAKRA

USER MANUAL



- Long press"   to turn on or off
- Short press"   to shift 10 different patterns
- The magnetic charging port 

SPECIFICATION

Material :	Silicone+ABS
Unit size :	L144*W51.5*69.4mm
Mode :	6 different patterns
Charge time :	2 hours
Using time :	60 minutes on highest speed 90 minutes on lowest speed
Waterproof :	IPX7

PRODUCT DESCRIPTION AND FEATURES

1. Material: Ultra-premium silicone. 100% safe, phthalate-free and latex-free
2. Waterproof
3. Rechargeable : no need for batteries, uses USB plug-in (can charge device on computer)
3. 6 different patterns
4. No medical claims are warranted or implied by use of this product.
5. USB + Magnetic Rechargeable

SAFETY AND DIRECTIONS

1. Remove toy from packaging.
2. Make sure the product is 100% dry before charging.
3. Use only the charging cable included in the box.
4. To charge, use magnetic charging cable to contact the magnetic port of the vibrator and the other end to a power source (USB)
5. Before first use, the vibrator needs to be charged between 4-6 hours using the designated charging cable (included).
6. Initial Charging Time: between 4-6 hours. Normal Charging Time after the first use; 2 hours
7. Charge the toy. The light will blink on and off during charging and will light up continuously when it is fully charged.
8. Wash with Share Satisfaction toy wash.
9. Apply Share Satisfaction water-based lubricant.
10. This product has a 12 month warranty, which covers product replacement for manufacturing defects only. No medical claims are implied or warranted by use of this product.
11. The crossed out wheeled bin on the product indicates that this product should not be treated as household waste.
12. Warning - sold as an adult novelty only, not for medical use. This appliance is not intended for use by children or persons with reduced physical, sensory or mental capabilities. To avoid electric shock, do not use charger near water. Do not use on swollen or inflamed areas of skin. Discontinue use if discomfort occurs.