

SHARE SATISFACTION DASH II

USER MANUAL



- Long press "⏻" ④ to turn on or off.
- When the main body is on, long press "⏻" ④ to turn vibration on or off and a short press ③ to switch between the 10 vibration modes. The LED lights will change with all 10 vibration modes.

SPECIFICATION

Material :	Silicone+ABS
Remote size :	64mm x 37mm
Unit Size :	92.5mm x 51mm ring 32mm
Mode :	10 Mode Vibration
Charge time :	70 mins
Using time :	40 mins
Waterproof :	IPX5
Remote control distance :	10 metres

PRODUCT DESCRIPTION AND FEATURES

1. 10 Modes of vibration.
2. Remote control – The remote can change the vibration intensity and mode whilst in use. Either partner can use the remote and it works up to a distance of 10 meters.
3. Eco-friendly USB Rechargeable - Simply insert the charger into the toy and/or remote where indicated by DC ⏻ .
4. Made from liquid silicone – soft, safe and reliable.
5. Waterproof - the ring is waterproof, the remote is splashproof.

SAFETY AND DIRECTIONS

1. Remove toy from packaging.
2. Charge both the toy and remote control. The purple light will blink on and off during charging and will light up continuously when it is fully charged.
3. Wash with Share Satisfaction toy wash.
4. Apply Share Satisfaction water-based lubricant. Turn on your 'Dash sex II toy by pressing the ON button on both the toy and remote control.
5. Gently put the ring onto an erect penis with the panel facing outwards. The outer ends will stimulate your partners clitoris.
6. Have you partner join you to have sex and enjoy the shared satisfaction.
7. To change the mode of vibration, simply press the mode button on the remote.
8. This product has a 12 month warranty, which covers product replacement for manufacturing defects only. No medical claims are implied or warranted by use of this product.
9. The crossed out wheeled bin on the product indicates that this product should not be treated as household waste.
10. Warning – sold as an adult novelty only, not for medical use. This appliance is not intended for use by children or persons with reduced physical, sensory or mental capabilities. To avoid electric shock, do not use charger near water. Do not use on swollen or inflamed areas of skin. Discontinue use if discomfort occurs.