


SHARE SATISFACTION DASH

USER MANUAL



- Long press "⏻" Ⓞ to turn on or off.
- Short press "⏻" Ⓞ to switch between the 10 vibration modes.
- The LED panel Ⓞ lights will change with all 10 vibration modes.

SPECIFICATION

Material :	Silicone+ABS
Unit size :	92.5mm x 51mm ring 32mm
Mode :	10 Mode Vibration
Charge time :	100 mins
Using time :	50 mins
Waterproof :	IPX5

PRODUCT DESCRIPTION AND FEATURES

1. 10 Modes of vibration.
2. Short presses can change the vibration intensity and mode whilst in use.
3. Eco-friendly USB Rechargeable - Simply insert the charger into the toy where indicated by DC Ⓞ.
4. Made from liquid silicone – soft, safe and reliable.
5. Waterproof.

SAFETY AND DIRECTIONS

1. Remove toy from packaging.
2. Charge the toy. The pink light will blink on and off during charging and will light up continuously when it is fully charged.
3. Wash with Share Satisfaction toy wash.
4. Apply Share Satisfaction water-based lubricant.
5. Turn on your 'Dash' sex toy by pressing the ON button.
6. Gently put the ring onto an erect penis with the panel facing outwards.
7. The toys outer ends will vibrate to stimulate your partners clitoris.
8. Have you partner join you for intercourse and enjoy the shared satisfaction.
9. To change the mode of vibration, simply press the on/off button on the unit.
10. This product has a 12 month warranty, which covers product replacement for manufacturing defects only. No medical claims are implied or warranted by use of this product.
11. The crossed out wheeled bin on the product indicates that this product should not be treated as household waste.
12. Warning – sold as an adult novelty only, not for medical use. This appliance is not intended for use by children or persons with reduced physical, sensory or mental capabilities. To avoid electric shock, do not use charger near water. Do not use on swollen or inflamed areas of skin. Discontinue use if discomfort occurs.