


SHARE SATISFACTION ELECTRA

USER MANUAL



Long press to turn on or off - The unit will be on standby. Short press on unit or remote to cycle through 10 modes of suction & 20 modes of vibration. Complete with DC charging port.

SPECIFICATIONS

Material : Silicone + ABS
Unit size : 16 x 4.5cm
Mode : 10 suction & 20 vibration patterns
Charge time : 2 hours
Using time : 60 minutes on highest speed 90 minutes on lowest speed
Waterproof : IPX5

FEATURES

1. Material: Ultra-premium silicone. 100% safe, phthalate-free and latex-free.
2. Waterproof
3. Rechargeable
4. 10 Suction patterns
5. 20 Vibration patterns

SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Ensure the product is 100% dry before charging.
3. Use only the charging cable included in the box.
4. To charge, insert DC charging cable pin head into the pin port of the vibrator and the other end to a power source (USB).
5. Before first use charge between 4-6 hours. Thereafter charge time is 2 hours.
7. Charge the toy. The light will blink on and off during charging and will light up continuously when it is fully charged.
8. Wash with Share Satisfaction toy wash.
9. Apply Share Satisfaction water-based lubricant and use as desired. You can use both ends of this lovely vibrator. The tail end has a variable frequency vibration.
10. This product has a 12-month warranty, which covers product replacement for manufacturing defects only.
11. No medical claims are implied or warranted by use of this product.
12. Warning - This product is for adults only. Do not use on swollen, inflamed or broken skin
13. Do not use charger near water.