




FLINT USER MANUAL



- Long press  to turn on or off
- Short press  or on the remote control to cycle through 6 modes of vibration
- DC charging port  - on the back of the unit


SPECIFICATIONS

Size: 13 x 6 x 6cm
Mode: 6 vibration patterns
Material: ABS + Silicone
Charging Time : 40 min
User time: 50min
Waterproof: IPX6 - remote control is not waterproof and is battery operated

FEATURES

1. Material: Ultra-premium silicone. 100% safe, phthalate-free and latex-free
2. Use solo or together
3. Waterproof and rechargeable
4. Remote controlled
5. 6 vibration patterns

SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Before first use, the vibrator needs to be charged for 4-6 hours. Thereafter, charge time is 60 minutes.
3. Charge the toy. Make sure the product is 100% dry before charging. Use only the charging cable included in the box.
4. To charge, insert DC charging cable pin head into the pin port on the base of the unit  and the other end to a power source (USB).
5. The light will blink on and off during charging and will light up continuously when unit is fully charged.
6. Wash with Share Satisfaction toy wash.
7. Apply Share Satisfaction water-based lubricant.
8. If the toy is used vaginally or anally ensure it is cleaned thoroughly before using in another area.
9. This product has a 12 month warranty, which covers product replacement for manufacturing defects only.
10. Warning - this product is for adults only. Do not use on swollen, inflamed or broken skin. No medical claims are warranted or implied by the use of this product.
11. Do not charge near water.



SHARESATISFACTION.COM