


## GALACTIC THRUSTING RABBIT VIBRATOR



Long press the power button for 3 seconds to turn on and off.  
Short press the same button to cycle through 5 thrusting modes in either clockwise or anticlockwise direction.  
Short press the vibration mode button to choose between 3 vibration speeds and 6 vibration patterns.

## SPECIFICATIONS

Material: Silicone  
Waterproof: Splashproof at an IPX5 level  
Modes: 6 vibration patterns  
Battery: USB rechargeable  
Charge time: 1-2 hours  
Using time: 1-2 hours of use

## FEATURES

Made of ultra soft silicone  
USB rechargeable  
Thrusting and rotating motion  
6 patterns  
5 thrusting modes

## SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Ensure the product is 100% dry before charging.
3. Use only the charging cable included in the box.
4. To charge, attach the magnetic charger to the charging port on the back of the unit and the other end to a power source (USB).
5. Before first use charge between 4-6 hours. Thereafter charge time is 2 hours.
6. Charge the toy. The light will blink on and off during charging and will light up continuously when it is fully charged.
7. Wash with Share Satisfaction toy wash.
8. Apply Share Satisfaction water-based lubricant and use as desired.
9. This product has a 12-month warranty, which covers product replacement for manufacturing defects only.
10. No medical claims are implied or warranted by use of this product.
11. Warning – This product is for adults only. Do not use on swollen, inflamed or broken skin
12. Do not use charger near water.



SHARESATISFACTION.COM

12x7cm