

JINA USER MANUAL



The Jina Cock Teaser is designed to take you to erect in no time by snugly surrounding the entire head with powerful vibration. 10 vibrational patterns encircle the sensitive penis head for mind-blowing masturbation pleasure. Waterproof design can be enjoyed in any wet environment.

SPECIFICATIONS

Material: ABS + Liquid Silicone
Size: 140mm x 50mm
Mode: 10 Mode Vibration
Charge time: 120 mins
Using time: 90 mins
Waterproof: IPX7100% waterproof

FEATURES

1. Eco-friendly USB Rechargeable - Simply insert the charger into the toy and/or remote where indicated by DC Ⓞ
2. Made from liquid silicone – soft, safe and reliable.
3. Waterproof - can be used in the shower, bath or hot tub.

SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Charge the toy. The light will blink on and off during charging and will light up continuously when unit is fully charged.
3. Wash with Share Satisfaction toy wash.
4. Apply Share Satisfaction water-based lubricant
5. Turn on your 'JINA' sex toy by pressing the Ⓞ button on the toy.
6. Gently insert the head of the penis into the cup.
7. To change the mode of vibration, simply press the Ⓞ button on the toy.
8. Clean the toy with Share Satisfaction toy wash after use and dry with a lint free cloth before storing in a toy bag.
9. This product has a 12 month warranty, which covers product replacement for manufacturing defects only.
10. This product is for adults only. No medical claims are implied or warranted by use of this product.
11. Do not charge near water.



SHARESATISFACTION.COM