


SHARE SATISFACTION JUICY

USER MANUAL



Long press to turn on or off. Short press to cycle through 5 modes of vibration. Swipe control left to right to increase speed. Use DC port  for charging.


SPECIFICATIONS

Material : Silicone + ABS
Unit size : 12.5 x 5 x 3.5cm
Mode : 5 vibration patterns
Charge time : 2 hours
Using time : 60 minutes on highest speed 90 minutes on lowest speed
Waterproof : IPX7

FEATURES

1. Material: Ultra-premium silicone. 100% safe, phthalate-free and latex-free
2. Waterproof
3. Rechargeable
4. 5 vibration patterns & 3 swipe intensities
5. Memory function will remember the intensity and frequency when powered off and resume at the same level.

SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Ensure the product is 100% dry before charging.
3. Use only the charging cable included in the box.
4. To charge, insert DC charging cable pin head into the pin port at the end of the vibrator  and the other end to a power source (USB)
5. Before first use, the vibrator needs to be charged between 4-6 hours Thereafter charge time is 2 hours.
7. Charge the toy. The light will blink on and off during charging and will light up continuously when it is fully charged.
8. Wash with Share Satisfaction toy wash.
9. Apply Share Satisfaction water-based lubricant and use as desired.
10. This product has a 12-month warranty, which covers product replacement for manufacturing defects only.
11. No medical claims are implied or warranted by use of this product.
12. Warning – This product is for adults only. Do not use on swollen, inflamed or broken skin
13. Do not use charger near water.