




LINA USER MANUAL



- Long press  to turn on or off
- Short press  or on the remote control to cycle through 5 modes of vibration
- Swipe the slide controller to change intensity of vibration
- DC charging port  – on the back of the unit


SPECIFICATIONS

Size: 17.5 x 5 x 4.3cm
Mode: 5 vibration patterns
Material: ABS + Silicone
Charging Time : 120 min
User time: 50 min
Waterproof: IPX6

FEATURES

1. Material: Ultra-premium silicone. 100% safe, phthalate-free and latex-free
2. Waterproof
3. Rechargeable
4. Dual motor with 5 vibration patterns in 3 speeds
5. Use solo or together

SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Before first use, the vibrator needs to be charged for 4-6 hours. Thereafter, charge time is 50 minutes.
3. Charge the toy. Make sure the product is 100% dry before charging. Use only the charging cable included in the box.
4. To charge, insert DC charging cable pin head into the pin port on the back of the unit  and the other end to a power source (USB).
5. The light will blink on and off during charging and will light up continuously when unit is fully charged.
6. Wash with Share Satisfaction toy wash.
7. Apply Share Satisfaction water-based lubricant.
8. This product has a 12 month warranty, which covers product replacement for manufacturing defects only.
9. Warning – this product is for adults only. Do not use on swollen, inflamed or broken skin. No medical claims are warranted or implied by the use of this product.
10. Do not charge near water.



SHARESATISFACTION.COM