

SHARE SATISFACTION MILA

USER MANUAL



Operation without remote control:

- Long press "⏻" ① for 3 seconds to turn on or off and the toy will be on standby mode. When powered on, short press "⏻" ① and the toy will change frequency. The lights will change with all 10 vibration modes.

Operation with remote control:

- When the main body is on, short press "⏻" ② to change the frequency. The lights will change with all 10 vibration modes. Long press "⏻" ② for 3 seconds to enter standby mode.

Note: the white light will blink on and off during charging, and will then light up continuously when toy is fully charged.

SPECIFICATION

| | |
|--------------------------|-------------------|
| Material : | Liquid silicone |
| Size: | 85mm x 38mm x34mm |
| Mode: | 10 Mode Vibration |
| Charge time : | 70mins |
| Using time: | 40mins |
| Waterproof : | IPX7 |
| Remote control distance: | 10 metre |

PRODUCT DESCRIPTION AND FEATURES

1. Dual stimulation – intensify shared pleasure during sex. Simply insert the thinner arm of the toy into the vagina for G-spot stimulation. The larger arm is for direct external clitoral stimulation.
2. Remote control – The remote can change the vibration intensity and mode whilst in use. Either partner can use the remote and it works up to a distance of 10 meters.
3. Eco-friendly USB Rechargeable – Simply insert the charger into the toy and/or remote where indicated by DC ⏻.
4. Made from liquid silicone – soft, safe and reliable.
5. Waterproof - Both the toy and remote are waterproof and can be used in the shower, bath or hot tub.

SAFETY AND DIRECTIONS

1. Remove toy from packaging.
2. Charge both the toy and remote control. The white light will blink on and off during charging and will light up continuously when it is fully charged.
3. Wash with Share Satisfaction toy wash.
4. Apply Share Satisfaction water-based lubricant.
5. Turn on your 'Mila' sex toy by pressing the ON button on both the toy and remote control.
6. Gently insert the smaller G-spot stimulator into the vagina, resting the external clitoral stimulator on the clitoris. Have you partner join you to have sex and enjoy the shared satisfaction.
7. To change the mode of vibration, simply press the mode button on the remote.
8. This product has a 12 month warranty, which covers product replacement for manufacturing defects only. No medical claims are implied or warranted by use of this product.
9. The crossed out wheeled bin on the product indicates that this product should not be treated as household waste.
10. Warning – sold as an adult novelty only, not for medical use. This appliance is not intended for use by children or persons with reduced physical, sensory or mental capabilities. To avoid electric shock, do not use charger near water. Do not use on swollen or inflamed areas of skin. Discontinue use if discomfort occurs.