





NINN USER MANUAL



- Long press  to turn on or off - toy will shut down automatically after 15 mins on standby
- Short press  or on the remote control to cycle through 9 modes of vibration
- Long press  to turn heat on or off
- DC charging port  - on back of the unit, near the bottom


SPECIFICATIONS

Size: 11.6 x 9.4 x 5.5cm
Mode: 9 vibration patterns
Material: ABS + Silicone
Charging Time : 50 minutes
User time: 50 minutes
Waterproof: IPX6 - remote control is not waterproof and is battery operated

FEATURES

1. Material: Ultra-premium silicone. 100% safe, phthalate-free and latex-free
2. Heating function - fully active 3 minutes after switching the unit on
3. Dual motor with 9 vibration patterns
4. Rechargeable and waterproof

SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Before first use, vibrator needs to be charged for 4-6 hours. Thereafter, charge time is 40 minutes.
3. Charge the toy. Make sure the product is 100% dry before charging. Use only the charging cable included in the box.
4. To charge, insert DC charging cable pin head into the pin port on the base of the unit  and the other end to a power source (USB).
5. The light will blink on and off during charging and will light up continuously when unit is fully charged.
6. Wash with Share Satisfaction toy wash.
7. Apply Share Satisfaction water-based lubricant.
8. The remote control is not waterproof and is battery operated.
9. This product has a 12 month warranty, which covers product replacement for manufacturing defects only.
10. Warning - this product is for adults only. Do not use on swollen, inflamed or broken skin. No medical claims are warranted or implied by the use of this product.
11. Do not charge near water.



SHARESATISFACTION.COM