


O-POD



- To turn on, LONG PRESS the power button.
- This puts the O-Pod into standby mode.
- SHORT PRESS to cycle through the 5 suction modes.
- Repower device within the charging case.

SPECIFICATIONS

Material : Silicone + ABS

Unit size : 5,2 x 2,4cm

Modes : 5 suction modes

Charge time : 2 hours

Using time : 60 minutes on high speed or 90 minutes on low speed

Waterproof : IPX6

FEATURES

- Material: Ultra-soft silicone.
- 100% safe, phthalate-free and latex-free.
- Waterproof.
- Recharges inside case.
- 5 suction patterns and whisper quiet.

SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Ensure the product is 100% dry before charging.
3. Use only the charging cable included in the box.
4. To charge: Place O-Pod inside case and attach the USB cable to the bottom of the case.
5. Before first use, charge between 1-2 hours. Thereafter, the charge time is 30 minutes.
6. The light will blink on and off during charging and will light up continuously when it is fully charged.
7. Wash with Share Satisfaction toy cleaner.
8. Apply Share Satisfaction water-based lubricant and use as desired.
9. This product has a 12-month warranty, which covers product replacement for manufacturing defects only.
10. No medical claims are implied or warranted by use of this product.
11. Warning – This product is for adults only. Do not use on swollen, inflamed or broken skin.
12. Do not use charger near water.



SHARESATISFACTION.COM

O-Pod User Manual