


PERI USER MANUAL



This powerful mini wand packs a punch with 5 intense vibration modes that will send delicious vibrations through your body.

This wand is splash proof - Do not submerge.

SPECIFICATIONS

Material: ABS + Liquid Silicone

Size: 38mm x 200mm

Mode: 10 Mode Vibration

Charge time: 120 mins

Using time: 75 mins

Waterproof: IPX5 100% waterproof

FEATURES

1. Eco-friendly USB rechargeable - simply attach the magnetic charger to the port on base.
2. Made from liquid silicone - soft, safe and reliable.
3. Waterproof.

SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Charge the toy. The light will blink on and off during charging and will light up continuously when unit is fully charged.
3. Wash with Share Satisfaction toy wash.
4. Apply Share Satisfaction water-based lubricant.
5. Turn on your 'PERI' sex toy by pressing the center button on the toy.
6. To change the mode of vibration, simply press the +/- button on the toy.
7. This product has a 12month warranty, which covers product replacement for manufacturing defects only.
8. This product is for adults only. No medical claims are implied or warranted by use of this product.
9. Do not charge near water.



SHARESATISFACTION.COM