

RAVI USER MANUAL



This unique vibrator boasts clitoral stimulator with 10 suction and 10 intense vibration patterns. It gently sucks and pulses against the clitoris on one side as the opposite slips into the vagina and stimulates the g-spot. It is fully waterproof so you can use it while taking a shower or relaxing in the tub.

SPECIFICATIONS

Material: ABS + Liquid Silicone
Size: 170 x 42 x 33mm
Mode: 10 Mode Vibration
10 Mode Suction
Charge time: 150 min
Using time: 90 min
Waterproof: 100% waterproof

FEATURES

1. Dual stimulation – intensify pleasure with clitoral suction and internal vibration.
2. Eco-friendly USB rechargeable - simply insert the charger into the toy and/or remote where indicated by DC Ⓢ
3. Made from liquid silicone – soft, safe and reliable.
4. Waterproof - can be used in the shower, bath or hot tub.

SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Charge the toy. The light will blink on and off during charging and will light up continuously when unit is fully charged.
3. Wash with Share Satisfaction toy wash.
4. Apply Share Satisfaction water-based lubricant.
5. Turn on your 'RAVI' sex toy by holding the 😊☹️ buttons on the toy.
6. Gently insert the smaller G-spot stimulator into the vagina, resting the external clitoral stimulator on the clitoris.
7. To change the mode of vibration, simply press the 😊☹️ buttons on the toy.
8. This product has a 12 month warranty, which covers product replacement for manufacturing defects only.
9. Warning – this product is for adults only. Do not use on swollen, inflamed or broken skin. No medical claims are warranted or implied by the use of this product.
10. Do not use charger near water.



SHARESATISFACTION.COM