


UNO USER MANUAL



The Uno vibe has a powerful motor which creates consistently strong vibrations. 10 vibration modes flow through this beautifully shaped vibe to be used solo or with a partner.

SPECIFICATIONS

Material: ABS + Silicone
Size: 27mm x 160mm
Mode: 10 modes vibration
Charge time: 60 mins
Using time: 60 mins
Waterproof: IPX 6 water resistant

FEATURES

1. Dual stimulation - intensify pleasure with clitoral and internal vibration.
2. Eco-friendly USB Rechargeable - Simply insert the charger into the toy and/or remote where indicated by DC Ⓢ
3. Made from liquid silicone - soft, safe and reliable.
4. Waterproof can be used in the shower - do not submerge.

SAFETY & DIRECTIONS

1. Remove toy from packaging.
2. Charge the toy. The light will blink on and off during charging and will light up continuously when unit is fully charged.
3. Wash with Share Satisfaction toy wash.
4. Apply Share Satisfaction water-based lubricant.
5. Turn on your 'UNO' sex toy by pressing the button Ⓢ on the toy.
6. To change the mode of vibration, simply press the button Ⓢ on the toy.
7. Clean the toy with Share Satisfaction toy wash after use and dry with a lint free cloth before storing in a toy bag.
8. This product has a 12 month warranty, which covers product replacement for manufacturing defects only.
9. This product is for adults only. No medical claims are implied or warranted by use of this product.
10. Do not charge near water.



SHARESATISFACTION.COM